



Installation procedure:

- A. ドライバークッション (2) をドライバーフレーム (3) の前面に取り付けます。ネジ穴を揃え、EVAシールがドライバフレームの端を超えて伸びないようにしてください。
- B. フロントバツプル (1) にドライバー (3) を取り付けます。M3フランジナット (アイテム4) を使用します (図1参照)。
- C. 両面テープでフロントケース (1) の内側壁に吸音材 (5) を取り付けます (図2参照)。
- D. スピーカーケーブル (アイテム7) とバインディングポスト (アイテム10) をリアケース (アイテム9) に取り付けます。ねじを締めます (アイテム10)。正しい向きと組み立て方法については、図に従ってください (図3参照)。
- E. 両面テープでリアケース (9) の内面に吸音材 (6) を貼り付けます。スピーカーケーブル (アイテム7) をエッグフォームの表面 (アイテム6) に配置します (図4参照)。
- F. ケース周囲グローブ (アイテム9) にシーリングストリップ (アイテム8) を取り付けます。シーリングストリップがきちんと並んでいて、端部の断面が互いに正しく接触していることを確認してください。
- G. ファストン端子 (項目7) をドライバコネクタ (項目3) に接続します。赤い色の端子はドライバーのプラス側に接続します。黒色端子はドライバーのマイナス側に接続します。
- H. リアケース (アイテム9) をフロントケース (アイテム1) の背面に慎重に置きます。向きが正しいことを確認してください。4x16ネジ (項目11) で締めます。
- I. ゴム製の脚 (アイテム12) をフロントケース (アイテム1) の底面に貼り付けます (図5参照)。

**** Note: 3" full range drivers are not included with the Tozzi One kit. Please purchase separately.**

Item	Name	Specification	Qty.
1	Front case	Assembly parts, ABS+Leather	1 set
2	Driver Cushion	EVA, Ø102x0.5mm, black	1 pcs
3	Driver	3" full range driver	1 pc
4	M3 Flange nut	M3x3.5mm, Steel plating Ni	5 pcs
5	Egg Foam	Foam, 620x90mm, T=30mm, black	1 pc
6	Egg Foam	Foam, 150x150mm, T=30mm, black	1 pc
7	Speaker cable	#16 AWG cable+Golden terminal	1 pc
8	Sealing strip	Foam silicone, Ø4.0x700mm	1 set
9	Rear case	ABS Rear case+PET Rating plate	5 pcs
10	Binding post	A set of red + A set of black	1 pair
11	Screw 4x16	M4x16mm, black	4 pcs
12	Rubber foot	Silicone, Ø11.8x4.6mm	3 pcs